


9. EXPLODED DIAGRAM & PARTS LIST



No.	Part No.	Description
01	AE1-01	Airbrush holder
02	AE1-02	Housing cover
03	AE1-03	Rubber motor guards
04	AE1-04	Air tube fittings
05	AE1-05A	Compressor (110V)
	AE1-05B	Compressor (230V)
06	AE1-06	Screw
07	AE1-07	Wire stay
08	AE1-08	On/Off switch
09	AE1-09	Fuse holder
10	AE1-10	Fuse 2.5A
11	AE1-11	Power cord port
12	AE1-12	Housing base
13	AE1-13	Filter B
14	AE1-14	Filter A
15	AE1-15	Air filter cap
16	AE1-16	Screw
17	AE1-17	Rubber feet
18	AE1-18	1/8" NPS male fitting
19	AE1-19US	Power cord (US)
	AE1-19UK	Power cord (UK)
	AE1-19IT	Power cord (ITA)