


# Grex CF15AA

## 25 Gauge 1" Crown Corrugated Nailer

# EXPLODED DIAGRAM



# Grex CF15AA

## 25 Gauge 1" Crown Corrugated Nailer

## PARTS LIST

Part No.	Description
15010	Trigger Valve Head
15011	Trigger Valve
15012	Spring
15013	Trigger Valve Guide
15023	Inlet Cap Gasket
15400	Deflector
15440	Trigger Valve Stem
15454	Primary Trigger
15470	Secondary Trigger
15510	End Cap
15774	Single Fire Trigger Assembly
15870	Seal
15880	Seal
23031	Pin
23052	Spring
23097	Latch
27012	Gun Body
27020	Cylinder
27050	Bottom Gasket
27130	Cylinder Spacer
27150	Cap Gasket
27160	Cap
27170	Collar
27180	Head Valve Piston
27190	Seal
27220	Spring
27520	Head Valve Assembly
30090	Safety Guide

Part No.	Description
45010	Bottom Cap
45015	Bumper
45016	Ram Seal
45020	Spacer
45030	Nose (45032)
45040	Nose Cover B
45050	Nose Cover A (45052)
45061	Magazine
45070	Safety Guide
45080	Latch Bracket
45122	Lamella Scorement (45120)
45140	Magazine Cover
45150	Pusher
45160	Plate
45170	Pusher Spring
45211	Magazine Latch Plate
45220	Safety
45281	Piston Ram Assembly
45371	Adjust Plate
45380	C-Ring
45390	Safety Spring
83004	Screw
88006	Hex. Soc. Head Screw
90001	Hex. Soc. Head Set Screw
91005	Hex. Soc. Head Set Screw
92004	Lock Nut
93004	Spring Pin
93008	Spring Pin

Part No.	Description
93021	Spring Pin
94001	Coupling Plug
95001	E-Ring
96005	O-Ring
96010	O-Ring
96011	O-Ring
96012	O-Ring
96013	O-Ring
96015	O-Ring
96043	O-Ring
96044	O-Ring
96045	O-Ring
96046	O-Ring
96047	O-Ring
96080	O-Ring
97002	Spring Washer
97003	Spring Washer
99002	Hex. Soc. Head Screw
99006	Hex. Soc. Head Screw
99015	Hex. Soc. Head Screw
99020	Hex. Soc. Head Screw
99024	Hex. Soc. Head Screw
99026	Hex. Soc. Head Screw
99031	Hex. Soc. Head Screw
99034	Hex. Soc. Head Screw
99036	Hex. Soc. Head Screw